

Dr. pen A6S

USER MANUAL

PLEASE READ THE MANUAL BEFORE USE









Wireless Mode

The instrument working with rechargeable battery

Wired Mode

The instrument working with alternating current





Preparation

- 1. Take out needle cartridge in the sterilized packaging
- 2.Fitting round slot 1 into 2 of machine, push needle cartridge horizontally up to the end.
- 3.Lock the needle cartridge by turning it to the counterclockwise
- 4.Turn the needle cartridge clockwise and then push out horizontally if you want to remove it.



5.Start the Dr.pen A6S

Press the power button for 2-3 seconds to start or shut down the device.

Attention

In order to protect the instrument well,do not invert the instrument to prevent the liquid backflow



How to operate

Adjustment of needle length

Adjust the depth of needle by turning the scale adjustment ring

Turn it clockwise.needle depth will be shorter Turn it counterclockwise.needle depth will be longer



Speed Display



Speed Adjustment

The speed after start the device is the same as the speed before shutdown

The speed changes once each time you press the button







Product name: Auto-stamp Motorized Meso Machine Model name: Dr pen A6S

Adapter: 5V-1000mA

Package Weight: 425g

Package Size: 169*123*56 mm

Packing List

Item	Quantity		
Hand Piece	1 pc		
Adapter	1 pc		
Manual	1 pc		
Power Cable	1 pc		
Charger	1 pc		
Batteries	2 pcs		
Needle Cartridge	2 pcs		



\otimes	Please be sure to read instructions before use and follow as described.
	Do not apply it to the man as follow: 1.Who has acute disease or blocky disease over 38 °C 2.Who has allow and hernophile 4.Who has high interval head 5.Whor opglady wisk headpall 6.Whot lakes medicines 7.Whot is under 12 years old
\otimes	Do not use it on the power other than AC 220V. It may cause fires or malfunction
\otimes	Do not use it near the place with high temperature, dust or humidity (Near the humidifier). It may cause malfunction.
\otimes	Do not repair, disassemble or alter the controller and the body. It may cause malfunction.
\otimes	Do not touch the device or detach the power cords with wet hands. It may cause electric shock.
\otimes	Do not use the stripped cord or propped cord. It may cause fires(Be sure to replace it with another).
\otimes	Do not use the propped cord which has crack or scares. It may cause scares on the skin.
\otimes	When you don't use it for a long time, unplug it from the outlet.
\otimes	Be sure to have an inspection for test. If any troubles are found, get it repaired.
\otimes	No one other than the operator can touch it. It may cause accidents or malfunction.

\sim	Alternating current	SN	Serial No
	Direct current	EC REP	EU Representative
	Class I equipment	Œ	CE mark
	Attention, consult accompanying documents		Manufacturer
М	Date of manufacture	F	Floating applied part



The warranty period of Dr pen A6S is 6 months. We offer repair to our products from the day they are purchased. If any of our products has damages or natural trouble. We offer repair or replacements

General maintenance

Make sure to inspect the device and adapter before use

Keep it with its power off.Wipe its surface out with a dry cloth

Keep it away from direct sunlight or high temperature and humidity

Do not leave the measurement, repair or alter of the device to non-professional staff

When you use the device which has not been used for a long time, make sure to check if it works properly with safety

Dr. pen A6S USER MANUAL